

Can I install an external antenna on the OBU?

The OBU communicates with satellites (GPS/GNSS) and mobile networks (GSM) and uses internal antennas to send or receive signals. It is possible to connect an external antenna in order to improve the communication quality and/or to reduce the exposure to electromagnetic fields.

Satellic does not offer any external antenna. You may buy it at your preferred supplier or get it installed by your workshop of choice. The external antenna is connected on the back side of the OBU to the GSM connector with a SMB male connector and to the GPS/GNSS connector with a MCX female connector. The gsm-antenna should support 900 and 1800 Mhz cellular communication (bi-band) The following pictures illustrate how to connect the antenna to your OBU.



